

DME PROLINK **FLAT PACK** Floor Mount Cabinet 42U 800mmW x 800mmD



Description

DME PROLINK has wide range of Floor Mount cabinets which are available in any number of configurations to suit any environment or application. Cabinet structure for self-assembly is in three flat packs which facilitates transport

Features & Benefits

- Material: Cold Rolled Steel
- Elegant exterior with supreme finish
- Static loading capability of up to 700 kg
- 19" Standard Mounting Rails
- Removable Side panels and Doors.
- Perforated Front and Rear door
- Top or bottom cable entry
- Fan Tray
- Optional: Key Lock arrangement for added security
- Equipped with Castors wheels / Leveling Feet
- Height (H): 42U | Width (W):800mm | Depth(D): 800mm
- 25 Years System Warranty

Standard Compliance

Comply with ANSI/EIA-310-D, DIN41491 – PART1, IEC297-2, DIN41494-PART7, GB.T3047.2-92

Standard Accessories with the Pack

- Screw and Nut
- 4Pcs Castors and Leveling Feet
- 2 Pcs of Fixed Shelves
- 4 Fans Tray

Optional Accessories

- Sliding Shelf
- Standard 6-Way Power Distribution Unit (PDUs can be customized)
- Other accessories based on customer requirements

Part Number


D325-F428080134BK-P

DME PROLINK ® Cabinet, Free Standing 42U, Perforated Front & Rear Doors, 800 Wide, 800 Deep, 3 Shelves, 1 PDU, 4 Fans, Black (Flat pack)

DME PROLINK **FLAT PACK** Floor Mount Cabinet 42U 800mmW x 800mmD

Cabinet Construction








No.	Specification	Qty.	Unit	Material	Surface Finish	Remark
1	Top Cover	1	PCS	SPCC Cold rolled steel 1.0 or 1.2	Powder coated	600mm depth for 1.0mm, above is 1.2mm
2	Bottom panel	1	PCS	SPCC Cold rolled steel 1.0 or 1.2	Powder coated	600mm depth for 1.0mm, above is 1.2mm
3	Mounting Profile	4	PCS	SPCC Cold rolled steel 1.5 or 1.8	Powder coated	
4	Mounting angle	6	PCS	SPCC Cold rolled steel 1.5	Powder coated	4pcs of lower 32U
5	Toughened glass or mesh front door	1	PCS	SPCC 1.5/Toughened glass 5.0	Powder coated	High Density vented door/ sheet steel door/ double section high density vented door optional
6	Frame	2	PCS	SPCC Cold rolled steel 1.2	Powder coated	/
7	Fan unit	1	PCS	SPCC Cold rolled steel 1.0	Powder coated	/
8	Fan	2	PCS	120*120*38mm	/	4pcs for over 600 width and 600 depth
9	Side panel	2	PCS	SPCC Cold rolled steel 1.0 or 1.2	Powder coated	600mm or 800mm depth for 1.0mm, above is 1.2mm
10	Rear door	1	PCS	SPCC Cold rolled steel 1.0 or 1.2	Powder coated	600mm or 800mm width for 1.0mm, above is 1.2mm
11	Spring lock	1	PCS	/	/	with 2 keys
12	Small round lock	1	PCS	/	Nickel coated	with 2 keys
13	M6 Screw and Square Nuts	20	SET	steel	Zinc coated	40sets for over 32U
14	Adjustable feet	4	PCS	steel	Zinc coated	/
15	Wheels	4	PCS	/	/	/



- ① Front Door
- ② Base
- ③ Adjustable Feet
- ④ Castors
- ⑤ Side Door
- ⑥ Rear Door
- ⑦ Frame
- ⑧ Mounting Rail
- ⑨ Mounting angle
- ⑩ Top Cover
- ⑪ Lock

DME PROLINK FLAT PACK Floor Mount Cabinet 42U 800mmW x 800mmD

Cabinet Assembly Manual

 <p>Step1: Use 16pcs of M8*12 hexagon socket screws and 16pcs of M8 flange nuts to assemble the top tray, bottom tray and frame .</p>	 <p>Step2: Use 6pcs of M4*8 self-tapping screws to assemble the top cover. Use 8pcs of M4*8 self-tapping screws to assemble the side panels.</p>	 <p>Step3: Use 4pcs of M4*8 self-tapping screws to assemble the fan tray.</p>
 <p>Step4: Use 24pcs of M6*12 screws, M6 cage nuts and plastic washers to assemble the horizontal supports.</p>	 <p>Step5: Use 24pcs of M6*12 screws, M6 cage nuts and M6 plastic washers to assemble the connect blocks.</p>	 <p>Step6: Use 24pcs of M6*12 screws, M6 flange nuts and M6 plastic washers to assemble the vertical supports.</p>
 <p>Step7: Use 12pcs of M6*12 screws, M6 cage nuts and M6 plastic washers to assemble the platen panels .</p>	 <p>Step8: Use 24pcs of M6*12 screws, M6 flange nuts and M6 plastic washers to assemble the vertical cable manager.</p>	 <p>Step9: Assemble the cover of vertical cable manager.</p>
 <p>Step10: Use 16pcs of M6*12 self-tapping screws to assemble the casters. And assemble the M12*L90 supporting leg.</p>	 <p>Step11: Assemble the two side doors.</p>	 <p>Step12: Use 4mm plastic washers to assemble the front door and rear door.</p>

Main Packing List

- | | |
|------------------------------|-----------------------------------|
| 1. Bottom Tray: 1 Pcs | 10. Fan Tray: 1 Pcs |
| 2. Top Tray: 1 Pcs | 11. Cover Panel: 3 Pcs |
| 3. Frame: 2 Pcs | 12. Vertical Cable Manager: 2 Pcs |
| 4. Horizontal Support: 6 Pcs | 13. Connect Block: 12 Pcs |
| 5. Vertical Support: 4 Pcs | |
| 6. Side Door: 2 Pcs | |
| 7. Front Door: 1 Pcs | |
| 8. Rear Door: 1 Pcs | |
| 9. Shelf: 3 Pcs | |

Accessories Packing List

- M12*L90 Supporting Feet: 4 Pcs
- Casters: 4 Pcs
- Side Panel: 4 Pcs
- M8*12 Hexagon Socket Screw: 16 Pcs
- M8 Flange Nut: 16 Pcs
- M6*12 Screw: 104 Pcs
- 4mm Plastic Washer: 2 Pcs
- M4*12 Self-Tapping Screws: 18 Pcs
- M6*12 Self-Tapping Screws: 16 Pcs
- M6 Cage Nut: 56 Pcs
- M6 Plastic Washer: 80 Pcs
- M6 Flange Nuts: 48 Pcs